


# Valve Body Assembly for Hot & Cold Adapter Valve



|   |          |                                       |
|---|----------|---------------------------------------|
| B | NLA      | Union Nut                             |
| C | NLA      | Inlet 3/8" Nut                        |
| D | NLA      | Valve Body                            |
| F | 99102078 | Packing Nut                           |
| G | 99010538 | O-Ring (PK/10)                        |
| H | 99102079 | Back-Up Ring (PK/10)                  |
| J | 31346    | Brass Stem Assembly                   |
| K | NLA      | Spring                                |
| L | 99102180 | Red Fiber Washer (PK/10)              |
| N | 99102083 | Hot And Cold Tee With Connectors      |
| O | 99102084 | Gasket (PK/10)                        |
| P | 99102085 | Washer (PK/10)                        |
| R | 99102087 | Tee                                   |
| S | 30298    | 0.5 GPM Flo-Control Assembly          |
| T | 00990    | 1/2" X 5/8" X 1/16" O-Ring            |
| V | 30003    | 0.5 GPM Flo-Control                   |
| W | 00207    | 3/8" X 1/2" X 1/16" O-Ring            |
| X | NLA      | Flow Control Plug (Must buy Assembly) |