


EcoPower® Flush Valve,
Toilet, Exposed, 1.28 Gpf
24" VB



TOTO

EcoPower® Flush Valve,
Toilet, Exposed, 1.28 Gpf
24" VB

Item	Part	Description
1	99881332	Cover, top
2	99490914	Screw w/wrench set, exposed
3	99881336	Extension harness (3 type/bag)
4	99881337	Sensor unit
5	99814587	Bracket, sensor w/screw (20D)
6	99881339	Glass, sensor window, exposed
7	99822383	Controller unit, C
8	99881340	Screw, controller mount (2/bag)
9	99940121	Screw (4/bag)
10	99822379	Screw, cover, valve (5/bag)
11	99881334	Cover, lower, B
12	99822387	Solenoid unit & diaphragm assy
13	99287429	Clamp set (10/bag)
14	99888342	Valve assy, exposed, toilet
15	99822388	Valve cap assembly
16	99822390	O-ring, valve cap top (10/bag)
17	47105	O-ring, valve cap botm (10/bag)
18	47107	U-packing, piston (10/bag)
19	99340341	Piston assembly
20	47103	Seat packing set
21	99122240	O-ring, screen nut (10/bag)
22	99287444	Push button assembly
23	99287446	EcoPower generator, toilet
24	99712858	Screw, EcoPower generator
25	47110	Tailpiece
26	47106	Nut, tailpiece/angle stop
27	47109	Locking ring set, tailpiece (10/bag)
28	47101	O-ring, tailpiece (10/bag)
29	99881333	Cover, lower, A
30	99065714	Back-up battery
31	99783059	O-ring (1/bag)

TOTO