


Couplings & Gaskets (F-2-A)



1-3	99101725	3/4" Coupling Assembly CP
	99040057	3/4" Coupling Assembly RB
	43242	1" Coupling Assembly CP
	43231	1-1/4" Coupling Assembly CP
	99086777	1-1/4" Coupling Assembly RB
	43232	1-1/2" Coupling Assembly CP
	99162647	1-1/2" Coupling Assembly RB
3-4	99061405	1-1/2" Coupling Assembly CP
	99101747	1-1/2" Coupling Assembly RB
1	43233	3/4" SJ Gasket
	99101794	1" SJ Gasket
	43235	1-1/4" SJ Gasket
	43236	1-1/2" SJ Gasket
2	43237	3/4" Friction Ring
	99101794	1" Friction Ring
	43239	1-1/4" Friction Ring
	43240	1-1/2" Friction Ring
3	*	3/4" Coupling CP
	*	3/4" Coupling RB
	*	1" Coupling CP
	*	1-1/4" Coupling CP
	*	1-1/4" Coupling RB
	99220077	1-1/2" Coupling CP
	*	1-1/2" Coupling RB
4	43245	1-1/2" Gasket
5	99190320	1-1/2" Rigid Seat
3-5	99160247	1-1/2" w/S21 Seat

* N/A Order Appropriate Coupling Assembly